

**TOSHIBA**


***VF-AS1/PS1***

***PDP002Z (PROFIBUS DP)***



***Feb.2008***

# Overview


This option allows the VF-AS1/PS1 inverter to be communicated with the cyclic command transmission and monitoring of the original profile ("USER DEFINE") of our company other than application profile "Profile for Variable Speed Drives PROFIdrive (3.072)" which PROFIBUS define



# Exterior features



# Status indicator



The PDP002Z has two LEDs, ST (status) and DX (data exchange) to indicate the statuses of PROFIBUS-DP and the PDP002Z itself.

## ST (Status): Red LED

LED	Meanings
Off	No diagnostics present
Flashes	Waiting for parameterisation or configuration
Lights	DP status error * For example, a station address is not set correctly.

## DX (Data exchange): Green LED.

Indicates the status of the PROFIBUS network.

It lights when the PDP002Z is on-line and data exchange is possible.

# Inverter Parameter Settings

Parameter	Function	Adjustment range	Default setting
<i>F830*</i>	Communication option setting 1 (PPO TYPE)	0: None 1: PPO TYPE 1 2: PPO TYPE 2 3: PPO TYPE 3 4: PPO TYPE 4	0
<i>F831</i> - <i>F846</i>	Communication option setting 2 - 13	Refer to section 4.	0
<i>F851</i>	Inverter operation at the communications loss action (Network wire breaks)	0: Stop and break of connection 1: None 2: Deceleration stop 3: Coast stop 4: Emergency stop 5: Preset speed operation command (Operating at the preset speed operation frequency set with <i>F852</i> )	0
<i>F852</i>	Preset speed operation selection	0: None 1 to 15: Preset speed	0
<i>F853</i>	Monitoring of communication device station address	Displays the station address assigned with the DIP switch. 0 to 125	2
<i>F854**</i>	Monitoring of communications device's baud rate	Displays the network communication speed set with the DIP switch. 0: 12 Mbit/s 1: 6 Mbit/s 2: 3 Mbit/s 3: 1.5 Mbit/s 4: 500 kbit/s 5: 187.5 kbit/s 6: 93.75 kbit/s 7: 45.45 kbit/s 8: 19.2 kbit/s 9: 9.6 kbit/s 255: Disabled	0


\* When the parameters are changed, the power must be cycled to the VF-AS1/PS1 for the changes to take effect.

\*\* The baud rate of the PDP002Z is automatically set by configuration a baud rate for the master.

# Inverter Parameter Settings

<i>F831 - F835</i> setup value	<i>F841 - F845</i> setup value
0: No action	0: No action
1: FA06 (ALCAN2 command 1)	1: FD01 (Inverter status 1)
2: FA23 (ALCAN2 command 2)	2: FD00 (Output frequency, 0.01Hz)
3: FA07 (ALCAN2 frequency command, 0.01Hz)	3: FD03 (Output current, 0.01%)
4: FA33 (Torque command, 0.01%)	4: FD05 (Output voltage, 0.01%)
5: FA50 (Terminal output)	5: FC91 (Inverter alarm)
6: FA51 (Analog output (FM) data from comm.)	6: FD22 (PID feedback value, 0.01Hz)
7: FA52 (Analog output (AM) data from comm.)	7: FD06 (Input terminal status)
8: F601 (Stall prevention level, %)	8: FD07 (Output terminal status)
9: F441 (Power running torque limit 1 level, 0.01%)	9: FE36 (VI/II input)
10: F443 (Regenerative braking torque limit 1 level, 0.01%)	10: FE35 (RR/S4 input)
11: F460 (Speed loop proportional gain)	11: FE37 (RX input)
12: F461 (Speed loop stabilization coefficient)	12: FD04 (Input voltage (DC detection), 0.01%)
	13: FD16 (Speed feedback (real-time value))
	14: FD18 (Torque, 0.01%)
	15: FE60 (My monitor)
	16: FE61 (My monitor)
	17: FE62 (My monitor)
	18: FE63 (My monitor)
	19: F880 (Free notes)
	20: FD29 (Input power, 0.01kW)
	21: FD30 (Output power, 0.01kW)
	22: FE14 (Cumulative operation time, 1 hour)
	23: FE40 (FM terminal output monitor)
	24: FE41 (AM terminal output monitor)

# PRO TYPE



PKW : Parameter ID/value

PZD : Process Data, cyclically transferred

PKE : Parameter ID (1st and 2nd octet)

IND : Sub-index (3rd octet), 4th octet is reserved

PWE : Parameter value (5th until 8th octet)

STW : Control word


HSW : Main setpoint

ZSW : Status word

HIW : Main actual value

For accessing inverter's parameter, please select PROTYPE 1 or 2. PZD3 to 6, it depends on master.

# State machine





# State machine

Please refer details of following commands in the function manual.

STW Control Word Data

ZSW Status Word Data

## Example of STW and ZSW in PROFIdrive profile

HSW---the frequency reference

HIW---shows a output frequency while running

### **CW(Control Word)**

### **ST(Status Word)**

0x0406	0000 0100 0000 0110	Not ready	→	0x0231	0000 0010 0011 0001
0x0407	0000 0100 0000 0111	Ready	→	0x0233	0000 0010 0011 0011
0x044F	0000 0100 0100 1111	Operate	→	0x1E37	0001 1110 0011 0111
0x044B	0000 0100 0000 1011	Emergency	→	0x0250	0000 0010 0101 0000
0x0406	0000 0100 0000 0110	Not ready	→	0x0231	0000 0010 0011 0001
0x0407	0000 0100 0000 0111	Ready	→	0x0233	0000 0010 0011 0011
0x044F	0000 0100 0100 1111	Operate	→	0x1E37	0001 1110 0011 0111

# ***Difference between each version of PDP002Z***

V100: First released version

V101: Certificated by 'Profibus International' in 2007

## **Improvement items**

### 1. OFF3(Emergency stop)

In V100, the reset of OFF3 is necessary to turn off the power.

### 2. Station address

In V100, '0' and '126' of the station address are disabled with 'E-23'.

### 3. Parameter command length

Specifications: the Maximum length is 9 bytes.

In V100, it is enabled to receive over 10 bytes.

In V101, the parameter fault is caused by over 10 bytes.

Response of the parameter fault: 42 05

### 4. Version:

Version	V100	V101
Internal version	1601	1602(fe66 or fe67)

### 5. Version-up schedule: Releasing until end of Feb.2008

*End*