

## TOSVERT VF-FS1

---

Parameter List  
for CPU version 120/121

---

## VF-FS1 Parameter List for CPU version 120/121

Setting Date	
Customer	
End user	
Application	
Application No/Serial No	
Inverter's Type-Form	
Quantity	
Inverter's Serial No	
Motor's capacity	

If user's setting value is same as shipping value, entry column is blank.

You can confirm software version by the additional code on the nameplate and packing label

Additional code for V120/V121: (R6), (6) or (6B)

### -Terminal stand use state

	Terminal Name	Use state
Main terminal block	PA/+	
	PC/-	
	R/L1	
	S/L2	
	T/L3	
	U/T1	
	V/T2	
	W/T3	
Control terminal block	E/G	
	FLA	
	FLB	
	FLC	
	RY	
	RC	
	CC	
	VIA	
	VIB	
	PP	
	FM	
	F	
	R	
	RES	
	CC	
Setting of slide switch	PLC	
	P24	
	VIA	V / I
	FM	V / I
	SW4	SOURCE / PLC / SINK

---

## 1 User parameters

---

Title	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
<i>F1</i>	Operation frequency of operation panel	Hz	0.1/0.01	<i>L1</i> - <i>UL</i> when the value of <i>F103</i> is 1, this range is from <i>0.0</i> to the value of <i>FH</i> with free-unit.	0.0		3.2

---

## 2 Basic parameters

---

- Four automatic functions or basic parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
<i>RUF</i>	-	Wizard function	-	-	The wizard function refers to the special function of calling up ten frequently used parameters.	-		4.2.4 6.20.7
<i>RUH</i>	-	History function	-	-	Displays parameters in groups of five in the reverse order to that in which their settings were changed. * (Possible to edit)	-		4.2.5
<i>RUI</i>	0000	Automatic acceleration/deceleration	-	-	0: Disabled (manual) 1: Automatic 2: Automatic (only at acceleration)	0		5.1.1
<i>RU4</i>	0040	Parameter setting macro function	-	-	0: Disabled 1: Coast stop 2: 3-wire operation 3: External input UP/DOWN setting 4: 4-20 mA current input operation	0		5.2
<i>CMD</i>	0003	Command mode selection	-	-	0: Terminal board 1: Operation panel 2: RS485 communication	0		5.3 7.2
<i>FMD</i>	0004	Frequency setting mode selection 1	-	-	1: VIA 2: VIB 3: Operation panel 4: RS485 communication 5: UP/DOWN from external contact	1		5.3 6.5.1 7.1

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
<i>F75L</i>	0005	Meter selection	-	-	0:Output frequency 1:Output current 2:Set frequency 3:DC voltage 4:Output voltage command value 5:Input power 6:Output power 7:Torque 8:Torque current 9:Motor cumulative load factor 10:Inverter cumulative load factor 11:-(do not select) 12:Frequency setting value (after PID) 13:VIA Input value 14:VIB Input value 15:Fixed output 1 (Output current: 100%) 16:Fixed output 2 (Output current: 50%) 17:Fixed output 3 (Supposition output at <i>F75L</i> =17) 18:RS485 communication data 19:For adjustments ( <i>F7</i> set value is displayed)	0		5.4
<i>F7</i>	0006	Meter adjustment	-	-	-	-		
<i>FYP</i>	0007	Default setting	-	-	0: - 1: 50Hz default setting 2: 60Hz default setting 3: Default setting (Initialization) 4:Trip record clear 5:Cumulative operation time clear 6:Initialization of type information 7: Save user-setting parameters 8:Call user-defined parameters 9:Cumulative fan operation time record clear	0		4.2.7 4.2.8 5.5
<i>F r</i>	0008	Forward/reverse run selection (Operation panel operation)	-	-	0: Forward run 1: Reverse run 2: Forward run (F/R switching possible) 3: Reverse run (F/R switching possible)	0		5.6

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference																													
<i>A<sub>E</sub>C</i>	0009	Acceleration time 1	s	0.1/0.1	0.0-3200	*1		5.1.2																													
<i>d<sub>E</sub>C</i>	0010	Deceleration time 1	s	0.1/0.1	0.0-3200	*1																															
<i>F<sub>H</sub></i>	0011	Maximum frequency	Hz	0.1/0.01	30.0-200.0	80.0		5.7																													
<i>U<sub>L</sub></i>	0012	Upper limit frequency	Hz	0.1/0.01	0.5- <i>F<sub>H</sub></i>	50.0 (WP) 60.0 (WN)		5.8																													
<i>L<sub>L</sub></i>	0013	Lower limit frequency	Hz	0.1/0.01	0.0- <i>U<sub>L</sub></i>	0.0																															
<i>u<sub>L</sub></i>	0014	Base frequency 1	Hz	0.1/0.01	25-200.0	50.0 (WP) 60.0 (WN)		5.9																													
<i>u<sub>L</sub> u</i>	0409	Base frequency voltage 1	V	1/0.1	50-330 (200V class) 50-660 (400V class)	*2		5.9 6.12.5																													
<i>P<sub>E</sub></i>	0015	V/F control mode selection	-	-	0: V/F constant 1: Variable torque 2: Automatic torque boost control 3: Vector control 4: Advanced energy-saving 5: -(do not select) 6: PM motor control	1		5.10																													
<i>u<sub>b</sub></i>	0016	Torque boost 1	%	0.1/0.1	0.0-30.0	*1		5.11																													
<i>E<sub>H</sub>r</i>	0600	Motor electronic -thermal protection level 1	% (A)	1/1	10-100	100		5.12 6.17.1																													
<i>Q<sub>L</sub>n</i>	0017	Electronic -thermal protection characteristic selection *3	-	-	<table border="1"> <tr> <th>Setting</th> <th>Motor type</th> <th>Overload protection</th> <th>OL stall</th> </tr> <tr> <td>0</td> <td rowspan="4">Standard motor</td> <td>on</td> <td>off</td> </tr> <tr> <td>1</td> <td>on</td> <td>on</td> </tr> <tr> <td>2</td> <td>off</td> <td>off</td> </tr> <tr> <td>3</td> <td>off</td> <td>on</td> </tr> <tr> <td>4</td> <td rowspan="4">VF motor</td> <td>on</td> <td>off</td> </tr> <tr> <td>5</td> <td>on</td> <td>on</td> </tr> <tr> <td>6</td> <td>off</td> <td>off</td> </tr> <tr> <td>7</td> <td>off</td> <td>on</td> </tr> </table>	Setting	Motor type	Overload protection	OL stall	0	Standard motor	on	off	1	on	on	2	off	off	3	off	on	4	VF motor	on	off	5	on	on	6	off	off	7	off	on	0	5.12
Setting	Motor type	Overload protection	OL stall																																		
0	Standard motor	on	off																																		
1		on	on																																		
2		off	off																																		
3		off	on																																		
4	VF motor	on	off																																		
5		on	on																																		
6		off	off																																		
7		off	on																																		

\*1 : Default values vary depending on the capacity. See the table of the last page

\*2 : Inverter with a model number ending with

-WN : 230 (200V class), 460 (400V class)

-WP : 230 (200V class), 400 (400V class)

\*3 : on : valid, off : invalid

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
5r-1	0018	Preset-speed operation frequency 1	Hz	0.1/0.01	LL-UL	15.0		5.13
5r-2	0019	Preset-speed operation frequency 2	Hz	0.1/0.01	LL-UL	20.0		
5r-3	0020	Preset-speed operation frequency 3	Hz	0.1/0.01	LL-UL	25.0		
5r-4	0021	Preset-speed operation frequency 4	Hz	0.1/0.01	LL-UL	30.0		
5r-5	0022	Preset-speed operation frequency 5	Hz	0.1/0.01	LL-UL	35.0		
5r-6	0023	Preset-speed operation frequency 6	Hz	0.1/0.01	LL-UL	40.0		
5r-7	0024	Preset-speed operation frequency 7	Hz	0.1/0.01	LL-UL	45.0		
F---	-	Extended parameters	-	-	-	-	-	4.2.2
Gr.U	-	Automatic edit function	-	-	-	-	-	4.2.3

### 3 Extended parameters

- Input/output parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F 100	0100	Low-speed signal output frequency	Hz	0.1/0.01	0.0-F H	0.0		6.1.1
F 101	0101	Speed reach setting frequency	Hz	0.1/0.01	0.0-F H	0.0		6.1.3
F 102	0102	Speed reach detection band	Hz	0.1/0.01	0.0-F H	2.5		6.1.2
F 108	0108	Always-active function selection 1	-	-	0-72(No function)	0		6.3.1
F 109	0109	Analog/contact input function selection (VIA terminal)	-	-	0: VIA - analog input 1: VIA - contact input (Sink) 2: VIA - contact input (Source)	0		6.2.1
F 110	0110	Always-active function selection 2	-	-	0-72 (ST)	1		6.3.1
F 111	0111	Input terminal selection 1 (F)	-	-	0-72 (F)	2		6.3.2
F 112	0112	Input terminal selection 2 (R)	-	-	0-72 (R)	3		
F 113	0113	Input terminal selection 3 (RES)	-	-	0-72 (RES)	10		
F 118	0118	Input terminal selection 8 (VIA)	-	-	0-72 (SS1)	6		
F 130	0130	Output terminal selection 1A (RY-RC)	-	-	0-255 (LOW)	4		6.3.3
F 132	0132	Output terminal selection3 (FL)	-	-	0-255 (FL)	10		
F 137	0137	Output terminal selection 1B (RY-RC)	-	-	0-255 (always ON)	255		6.3.4
F 139	0139	Output terminal logic selection (RY-RC)	-	-	0: F 130 and F 137 1: F 130 or F 137	0		

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F 146	0146	Delay time for RY_RC relay	-	0.1/0.1	0.0-60.0	0.0		6.3.5
F 147	0147	Delay time for FL relay	-	0.1/0.1	0.0-60.0	0.0		
F 160	0160	Analog VIA detection level	%	1/1	0-100	0		6.3.6
F 161	0161	Analog VIA detection band	%	1/1	0-20	3		
F 162	0160	Analog VIB detection level	%	1/1	0-100	0		
F 163	0161	Analog VIB detection band	%	1/1	0-20	3		
F 167	0167	Frequency command agreement detection range	Hz	0.1/0.01	0.0-FH	2.5		6.3.5
F 170	0170	Base frequency 2	Hz	0.1/0.01	25.0-200.0	50.0 (WP) 60.0 (WN)		6.4.1
F 171	0170	Base frequency voltage 2	V	1/0.1	50-330 (200V class) 50-660 (400V class)	* 2		
F 172	0172	Torque boost 2	%	0.1/0.1	0.0-30.0	* 1		
F 173	0173	Motor electronic-thermal protection level 2	% (A)	1/1	10-100	100		5.12 6.4.1
F 185	0185	Stall prevention level 2	% (A)	1/1	10-110	110		6.4.1 6.17.2

\*1 : Default values vary depending on the capacity. See the table of last page

\*2 : Inverter with a model number ending with

-WN : 230 (200V class), 460 (400V class)

-WP : 230 (200V class), 400 (400V class)

- Frequency parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
<i>F200</i>	0200	Frequency priority selection	-	-	0: <i>F20d</i> (Switchable to <i>F207</i> by terminal input)	0		6.5.1 7.1
					1: <i>F20d</i> (Switchable to <i>F207</i> at less than 1.0Hz of designated frequency)			
<i>F201</i>	0201	VIA input point 1 setting	%	1/1	0-100	0		6.5.2
<i>F202</i>	0202	VIA input point 1 frequency	Hz	0.1/0.01	0.0-200.0	0.0		
<i>F203</i>	0203	VIA input point 2 setting	%	1/1	0-100	100		
<i>F204</i>	0204	VIA input point 2 frequency	Hz	0.1/0.01	0.0-200.0	50.0 (WP) 60.0 (WN)		
<i>F207</i>	0207	Frequency setting mode selection 2	-	-	1: VIA 2: VIB 3: Operation panel 4: RS485 communication 5: UP/DOWN from external contact	2		6.3.7 6.5.1 7.1
<i>F210</i>	0210	VIB input point 1 setting	%	1/1	0-100	0		6.5.2
<i>F211</i>	0211	VIB input point 1 frequency	Hz	0.1/0.01	0.0-200.0	0.0		
<i>F212</i>	0212	VIB input point 2 setting	%	1/1	0-100	100		
<i>F213</i>	0213	VIB input point 2 frequency	Hz	0.1/0.01	0.0-200.0	50.0 (WP) 60.0 (WN)		
<i>F240</i>	0240	Starting frequency setting	Hz	0.1/0.01	0.5-10.0	0.5		6.6.1
<i>F241</i>	0241	Operation starting frequency	Hz	0.1/0.01	0.0- <i>FH</i>	0.0		6.6.2
<i>F242</i>	0242	Operation starting frequency hysteresis	Hz	0.1/0.01	0.0- <i>FH</i>	0.0		
<i>F250</i>	0250	DC braking starting frequency	Hz	0.1/0.01	0.0- <i>FH</i>	0.0		6.7.1
<i>F251</i>	0251	DC braking current	% (A)	1/1	0-100	50		
<i>F252</i>	0252	DC braking time	s	0.1/0.1	0.0-20.0	1.0		

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F256	0256	Auto-stop in case of lower-limit frequency continuous operation time	s	0.1/0.1	0: Disabled 0.1-600.0	0.0		6.8
F264	0264	External contact input-UP response time	s	0.1/0.1	0.0-10.0	0.1		6.5.3
F265	0265	External contact input-UP frequency steps	Hz	0.1/0.01	0.0-FH	0.1		
F266	0266	External contact input-DOWN response time	s	0.1/0.1	0.0-10.0	0.1		
F267	0267	External contact input-DOWN frequency steps	Hz	0.1/0.01	0.0-FH	0.1		
F268	0268	Initial UP/DOWN frequency	Hz	0.1/0.01	LL - UL	0.0		
F269	0269	Change of the initial UP/DOWN frequency	-	-	0: Not changed 1: Setting of F25 changed when power is turned off	1		
F270	0270	Jump frequency 1	Hz	0.1/0.01	0.0-FH	0.0		6.9
F271	0271	Jumping width 1	Hz	0.1/0.01	0.0-30.0	0.0		
F272	0272	Jump frequency 2	Hz	0.1/0.01	0.0-FH	0.0		
F273	0273	Jumping width 2	Hz	0.1/0.01	0.0-30.0	0.0		
F274	0274	Jump frequency 3	Hz	0.1/0.01	0.0-FH	0.0		
F275	0275	Jumping width 3	Hz	0.1/0.01	0.0-30.0	0.0		
F294	0294	Forced fire-speed setting frequency	Hz	0.1/0.01	LL - UL	50.0		6.18
F295	0295	Bumpless operation selection	-	-	0:Disabled 1:Enabled	1		6.10

- Operation mode parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F300	0300	PWM carrier frequency	kHz	0.1/0.1	6.0 - 16.0	* 1		6.11
F301	0301	Auto-restart control selection	-	-	0: Disabled 1: At auto-restart after momentary stop 2: When turning ST-CC or off 3: At auto-restart or when turning ST-CC on or off 4: At start-up	0		6.12.1
F302	0302	Instantaneous Power failure coast stop selection	-	-	0: Disabled 1: -(Do not select) 2: Coast stop	0		6.12.2
F303	0303	Retry selection (number of times)	Times	1/1	0: Disabled 1-10	0		6.12.3
F305	0305	Over voltage limit operation (Slowdown stop mode selection)	-	-	0: Enabled 1: Disabled 2: Enabled (Quick deceleration) 3: Enabled (Dynamic quick deceleration)	2		6.12.4
F307	0307	Supply voltage correction (limitation of output voltage)	-	-	0: Supply voltage uncorrected, output voltage limited 1: Supply voltage corrected, output voltage limited 2: Supply voltage uncorrected, output voltage unlimited 3: Supply voltage corrected, output voltage unlimited	3		6.12.5
F311	0311	Reverse-run prohibition	-	-	0: Forward/reverse run permitted 1: Reverse run prohibited 2: Forward run prohibited			6.12.6
F312	0312	Random mode	-	-	0: Disabled 1: Automatic setting			6.11

\*1 : Default values vary depending on the capacity. See the table of last page.

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
<i>F315</i>	0316	Carrier frequency control mode selection	-	-	0:Carrier frequency not reduced automatically 1:Carrier frequency reduced automatically 2:Carrier frequency not reduced automatically Support for 400V models 3:Carrier frequency reduced automatically support for 400V models	1		6.11
<i>F320</i>	0320	Droop gain	%	1/1	0-100	0		6.13
<i>F323</i>	0323	Droop insensitive torque band	%	1/1	0-100	10		
<i>F359</i>	0359	PID control waiting time	s	1/1	0-2400	0		6.14
<i>F360</i>	0360	PID control	-	-	0: Disabled 1: Enabled (Feedback: VIA) 2: Enabled (Feedback: VIB)	0		
<i>F362</i>	0362	Proportional gain	-	0.01/0.01	0.01-100.0	0.30		
<i>F363</i>	0363	Integral gain	-	0.01/0.01	0.01-100.0	0.20		
<i>F366</i>	0366	Differential gain	-	0.01/0.01	0.00-2.55	0.00		
<i>F380</i>	0380	PID forward/reverse characteristic selection	-	1/1	0:Forward (Standard) 1:Reverse	0		
<i>F390</i>	0390	Lower Limit frequency for stall prevention	Hz	0.1/0.01	0.0- <i>LL</i>	0.0		-
<i>F391</i>	0391	Hysteresis for LL stop operation	Hz	0.1/0.01	0.0- <i>FH</i>	0.2		6.8.1
<i>F392</i>	0392	Restart deviation for LL stop operation	Hz	0.1/0.01	0.0- <i>FH</i>	0.0		
<i>F393</i>	0393	Restart feedback for LL stop operation	Hz	0.1/0.01	0.0- <i>FH</i>	0.0		
<i>F399</i>	0399	Factory setting parameter1 *1	-	1/1	0-255	0		-

\*1: factory setting parameter is only for the maker. Customers are not allowed to change it.

- Torque boost parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
<i>F400</i>	0400	Auto-tuning	-	-	0: Auto-tuning disabled 1: Application individual settings of <i>F402</i> (after execution:0) 2: Auto-tuning enabled (after execution:0)	0		5.10 6.15.1
<i>F401</i>	0401	Slip frequency gain	%	1/1	0-150	50		
<i>F402</i>	0402	Automatic torque boost value	%	0.1/0.1	0.0-30.0	* 1		
<i>F415</i>	0415	Motor rated current	A	0.1/0.1	0.1-200.0	* 1		
<i>F416</i>	0416	Motor no-load current	%	1/1	10-100	* 1		
<i>F417</i>	0417	Motor rated speed	min <sup>-1</sup>	1/1	100-15000	* 1		
<i>F418</i>	0418	Speed control response coefficient	-	1/1	1-150	40		
<i>F419</i>	0419	Speed control stability coefficient	-	1/1	1-100	20		

- Input/output parameters2

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
<i>F470</i>	0470	VIA input bias	-	-	0-255	128		6.5.4
<i>F471</i>	0471	VIA input gain	-	-	0-255	148		
<i>F472</i>	0472	VIB input bias	-	-	0-255	128		
<i>F473</i>	0473	VIB input gain	-	-	0-255	148		

\*1: Default values vary depending on the capacity. See the table of last page.

- Torque boost parameters2

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F480	0480	Exciting current coefficient	%	1/1	100-130	100		5.10 6.15.2
F481	0481	Power supply compensation filter	-	1/1	0-9999	0		6.17.16
F482	0482	Inhibitor filter	-	1/1	0-9999	442		
F483	0483	Inhibitor gain	-	0.1/0.1	0.0-300.0	100.0		
F484	0484	Power supply adjustment gain	%	0.1/0.1	0.0:Disable 0.1-2.0	0.0		
F485	0485	Stall prevention control coefficient 1	-	1/1	10-250	100		5.10 6.15.2
F492	0492	Stall prevention control coefficient 2	-	1/1	50-150	100		
F494	0494	Motor adjustment coefficient	-	1/1	0-200	* 1		
F495	0495	Maximum voltage adjustment coefficient	%	1/1	90-120	104		
F496	0496	Waveform switching adjustment coefficient	kHz	0.1/0.1	0.1-14.0	14.0		

\*1 : Default values vary depending on the capacity. See the table of last page.

- Acceleration/deceleration time parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F500	0500	Acceleration time 2	s	0.1/0.1	0.0-3200	* 1		6.16
F501	0501	Deceleration time 2	s	0.1/0.1	0.0-3200	* 1		
F502	0502	Acceleration/ deceleration 1 pattern	-	-	0: Linear 1: S-pattern 1 2: S-pattern 2	0		
F503	0503	Acceleration/ deceleration 2 pattern	-	-		0		
F504	0504	Selecting an acceleration/ deceleration pattern	-	-	1: Acceleration/deceleration 1 2: Acceleration/deceleration 2	1		
F505	0505	Acceleration/ deceleration 1 and 2 switching frequency	Hz	0.1/0.01	0.0- <i>LL</i>	0.0		
F506	0506	S-pattern lower-limit adjustment amount	%	1/1	0-50	10		
F507	0507	S-pattern upper-limit adjustment amount	%	1/1	0-50	10		

\*1 : Default values vary depending on the capacity. See the table of last page.

- Protection parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F601	0601	Stall prevention level 1	% (A)	1/1	10-110	110		6.17.2
F602	0602	Inverter trip retention selection	-	-	0:Canceled with the power off 1:Still retained with the power off	0		6.17.3
F603	0603	Emergency stop selection	-	-	0:Coast stop 1:Slowdown stop 2:Emergency DC braking	0		6.17.4
F604	0604	Emergency DC braking time	s	0.1/0.1	0.0-20.0	1.0		
F605	0605	Output phase failure detection mode selection	-	-	0:Disabled 1:At start-up (only one time after power is turned on) 2:At start-up (each time) 3:During operation 4:At start-up + during operation 5:Detection of cutoff on output side	0		6.17.5
F607	0607	Motor 150%-overload time limit	s	1/1	10-2400	300		6.17.1
F608	0608	Input phase failure detection mode selection	-	-	0: Disabled 1: Enabled	1		6.17.6
F609	0609	Small current detection current hysteresis	%	1/1	1-20	10		6.17.7
F610	0610	Small current trip/alarm selection	-	-	0: Alarm only 1: Tripping	0		
F611	0611	Small current detection current	% (A)	1/1	0-100	0		
F612	0612	Small current detection time	s	1/1	0-255	0		
F613	0613	Detection of output short-circuit during start-up	-	-	0: Each time(standard pulse) 1:Only one time after power is turned on (standard pulse) 2: Each time (short-time pulse) 3:Only one time after power is turned on (short-time pulse)	0		6.17.8

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
<i>F615</i>	0615	Over-torque trip/alarm selection	-	-	0: Alarm only 1: Tripping	0		6.17.9
<i>F616</i>	0616	Over-torque detection level	%	1/1	0-250	130		
<i>F618</i>	0618	Over-torque detection time	s	0.1/0.1	0.0-10.0	0.5		
<i>F619</i>	0619	Over-torque detection level hysteresis	%	1/1	0-100	10		
<i>F621</i>	0621	Cumulative operation time alarm setting	100 Time	0.1/0.1 (=10hours)	0.0-999.9	610.0		6.17.10
<i>F626</i>	0626	Over-voltage limit operation level	%	1/1	100-150	140		6.12.4
<i>F627</i>	0627	Under-voltage trip/alarm selection	-	-	0: Alarm only (detection level below 60%) 1: Tripping (detection level below 60%) 2: Alarm only (detection level below 50%, input reactor necessary)	0		6.17.12
<i>F632</i>	0632	Thermal memory selection	-	-	0:Deselect 1:Enabled	0		6.17.1
<i>F633</i>	0633	Trip at VIA low level input mode	%	1/1	0: Disabled, 1-100	0		6.17.13
<i>F634</i>	0634	Annual average ambient temperature (For parts replacement alarms)	-	-	1: -10 to +10 °C 2: 11-20 °C 3: 21-30 °C 4: 31-40 °C 5: 41-50 °C 6: 51-60 °C	3		6.17.14
<i>F644</i>	0644	Action in the event of VI/II analogue input wire breakage	-	1/1	0:Coast stop (Trip mode <i>E-1B</i> ) 1:Coast stop (Alarm mode <i>RL05</i> ) 2:Fallback speed (Alarm mode <i>RL05</i> ) 3:Speed maintain (Alarm mode <i>RL05</i> ) 4:Slowdown stop (Alarm mode <i>RL05</i> )	0		6.17.13

\*1 : Default values vary depending on the capacity. See the table of last page.

- Output parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F645	0645	PTC thermal selection	-	-	1:Disabled 2:Enabled (trip mode) 3:Enabled (alarm mode)	0		6.17.15
F646	0646	PTC detection resistor value	Ω	1/1	100-9999	3000		
F649	0649	Fallback speed	-	-	0-FH	0.0		6.17.13
F650	0650	Forced fire-speed control selection	-	-	0:Disabled 1:Enabled	0		6.18
F691	0691	Inclination characteristic of analog output	-	-	0: Negative inclination (downward slope) 1: Positive inclination (upward slope)	1		6.19.1
F692	0692	Bias of analog output	%	1/1	0-100	0		

- Operation panel parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F700	0700	Prohibition of parameter change	-	-	0: Permitted 1: Prohibited	0		6.20.1
F701	0701	Current/voltage display mode	-	-	0:% 1:A (ampere) /V (volt)	0		6.20.2
F702	0702	Frequency free unit magnification	Times	0.01/0.01	0.00: Free unit display disabled (display of frequency) 0.01-200.0	0.00		6.20.3
F703	0703	Frequency free unit conversion selection	-	1/1	0:All frequencies display free unit conversion 1:PID frequencies free unit conversion and FH range change (0.0-FH)	0		
F705	0705	Inclination characteristic of free unit display	-	-	0: Negative inclination (downward slope) 1: Positive inclination (upward slope)	1		
F706	0706	Bias of free unit display	Hz	0.01/0.01	0.00-FH	0.00		

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F 707	0707	Free step 1 (pressing a panel key once)	Hz	0.01/0.01	0.00: Disabled 0.01- <i>F H</i>	0.00		6.20.4
F 708	0708	Free step 2 (panel display)	-	1/1	0: Disabled 1-255	0		
F 710	0710	Standard monitor display selection	-	-	0:Operation frequency (Hz/free unit/step) 1:Frequency command (Hz/free unit/step) 2:Output current (%/A) 3:Inverter rated current (A) 4:Inverter load factor (%) 5:Output power (kW) 6:Frequency command after PID control (Hz/free unit/step) 7:Optional item specified from an external control unit 8:Output speed 9:Communication counter 10:Normal state communication counter	0		6.20.5
F 721	0721	Selection of operation panel stop pattern	-	-	0: Slowdown stop 1: Coast stop	0		6.20.6
F 730	0730	Prohibition of frequency setting on the operation panel (F L)	-	-	0: Permitted 1: Prohibited	0		6.20.1
F 732	0732	Prohibition of panel local/remote operation (LOC/REM key)	-	-	0:Permitted 1:Prohibited 2:Permitted (Cancelled with the power off)	0		
F 733	0733	Prohibition of Panel operation (RUN/STOP keys)	-	-	0: Permitted 1: Prohibited	0		
F 734	0734	Prohibition of panel emergency stop operation	-	-	0: Permitted 1: Prohibited	0		

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F 735	0735	Prohibition of panel reset operation	-	-	0: Permitted 1: Prohibited	0		
F 738	0738	Head of parameter display selection	-	-	0:AUF 1:AUH	0		6.20.7
F 748	0748	Integral output power retention selection	-	-	0:Disabled 1:Enabled	1		6.20.8
F 749	0749	Display unit selection for Integral output power	-	-	0:1=1kWh 1:0.1=1kWh 2:0.01=1kWh 3:0.001=1kWh	*1		

\*1 : Default values vary depending on the capacity. See the table of last page.

- Communication parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
F 800	0800	Communication rate	-	-	0: 9600bps 1: 19200bps	1		6.21
F 801	0801	Parity	-	-	0: NON (No parity) 1: EVEN (Even parity) 2: ODD (Odd parity)	1		
F 802	0802	Inverter number	-	1/1	0-247	0		
F 803	0803	Communication error trip time	s	1/1	0:Disabled 1-100	0		
F 805	0805	Communication waiting time	s	0.01/0.01	0.00: Regular communication 0.01-2.00	0.00		
F 806	0806	Setting of master and slave for communication between inverters	-	-	0: Slave (0 Hz command issued in case the master inverter fails) 1: Slave (Operation continued in case the master inverter fails) 2: Slave (Emergency stop tripping in case the master inverter fails) 3: Master (transmission of frequency commands) 4: Master (transmission of output frequency signals)	0		

Title	Communication No.	Function	Unit	Minimum setting unit Panel/Communication	Adjustment range	Default setting	User setting	Reference
<i>F811</i>	0811	Communication command point 1 setting	%	1/1	0-100	0		6.5.2 6.21
<i>F812</i>	0812	Communication command point 1 frequency	Hz	0.1/0.01	0.0-200.0	0.0		
<i>F813</i>	0813	Communication command point 2 setting	%	1/1	0-100	100		
<i>F814</i>	0814	Communication command point 2 frequency	Hz	0.1/0.01	0.0-200.0	50.0 (WP) 60.0 (WN)		
<i>F829</i>	0829	Selection of communication protocol	-	-	0: Toshiba inverter protocol 1: Modbus RTU protocol 2: Metasys N2 protocol 3: APOGEE FLN protocol 4: BAC-net protocol	0		6.21
<i>F851</i>	0851	Operation at communication error by disconnection	-	-	0:Inverter stop, communication, command frequency mode open (by <i>E00d</i> , <i>F00d</i> ) 1:None (continued operation) 2:Deceleration stop 3:Coast stop 4:Communication error ( <i>E--S</i> trip) or Network error ( <i>E--B</i> trip)	4		6.21
<i>F856</i>	0856	Number of motor poles for communication	-	-	1:2 poles 2:4 poles 3:6 poles 4:8 poles 5:10 poles 6:12 poles 7:14 poles 8:16 poles	2		
<i>F870</i>	0870	Block write data 1	-	-	0: No selection 1: Command 1	0		
<i>F871</i>	0871	Block write data 2	-	-	2: Command 2 3: Frequency command 4: Output data on the terminal board 5: Analog output for communications 6: Motor speed command	0		

Title	Communication No.	Function	Unit	Minimum setting unit Panel /Communication	Adjustment range	Default setting	User setting	Reference
F875	0875	Block read data 1	-	-	0: No selection 1: Status information 2: Output frequency 3: Output current 4: Output voltage 5: Alarm information 6: PID feedback value 7: Input terminal board monitor 8: Output terminal board monitor 9: VIA terminal board monitor 10: VIB terminal board monitor 11:Output motor speed monitor	0		6.21
F876	0876	Block read data 2	-	-		0		
F877	0877	Block read data 3	-	-		0		
F878	0878	Block read data 4	-	-		0		
F879	0879	Block read data 5	-	-		0		
F880	0880	Free notes	-	1/1	0-65535	0		6.22
F890	0890	Parameter for option 1	-	1/1	0-65535*1	0		
F891	0891	Parameter for option 2	-	1/1	0-65535*1	0		
F892	0892	Parameter for option 3	-	1/1	0-65535*1	0		
F893	0893	Parameter for option 4	-	1/1	0-65535*1	0		
F894	0894	Parameter for option 5	-	1/1	0-65535*1	0		
F895	0895	Parameter for option 6	-	1/1	0-65535*1	0		
F896	0896	Parameter for option 7	-	1/1	0-65535*1	0		
F897	0897	Parameter for option 8	-	1/1	0-65535	0		
F898	0898	Parameter for option 9	-	1/1	0-65535	0		
F899	0899	Parameter for option 10	-	1/1	0-65535	0		

- PM motor parameters

Title	Communication No.	Function	Unit	Minimum setting unit Panel /Communication	Adjustment range	Default setting	User setting	Reference
F910	0910	Step-out detection current level	% (A)	1/1	10-150	100		6.23
F911	0911	Step-out detection time	s	0.1/0.1	0.0: No detection 0.1-25.0	0.0		
F912	0912	High-speed torque adjustment coefficient	-	0.01/0.01	0.00-650.0	0.00		

\*1 : This default value is changed by setting value of F829

-Default settings by inverter rating

Inverter type	Acceleration Deceleration time	Torque boost value 1/2	PWM carrier frequency	Automatic torque boost value	Motor rated current	Motor no-load current	Motor rated speed		Motor adjustment coefficient	Display unit selection for integral output power
	<i>F001</i> <i>F500</i> <i>F501</i>	<i>F111</i> <i>F172</i> (%)	<i>F300</i>	<i>F402</i> (%)	<i>F415</i> (A)	<i>F416</i> (%)	<i>F417</i> (min <sup>-1</sup> )		<i>F494</i>	<i>F749</i>
							WN/ <i>EYP</i> :2	WP/ <i>EYP</i> :1		
VFFS1-2004PM	10	6.0	12.0	6.2	2.0	65	1680	1400	90	0
VFFS1-2007PM	10	6.0	12.0	5.8	3.4	60	1690	1408	80	0
VFFS1-2015PM	10	6.0	12.0	4.3	6.2	55	1690	1408	70	0
VFFS1-2022PM	10	5.0	12.0	4.1	8.9	52	1680	1400	70	0
VFFS1-2037PM	10	5.0	12.0	3.4	14.8	48	1690	1408	70	1
VFFS1-2055PM	10	4.0	12.0	3.0	21.0	46	1730	1441	70	1
VFFS1-2075PM	10	3.0	12.0	2.5	28.2	43	1730	1441	70	1
VFFS1-2110PM	10	2.0	12.0	2.3	40.6	41	1730	1441	60	1
VFFS1-2150PM	10	2.0	12.0	2.0	54.6	38	1730	1441	50	1
VFFS1-2185PM	30	2.0	8.0	2.0	68.0	36	1750	1458	50	1
VFFS1-2220PM	30	2.0	8.0	1.8	80.0	34	1750	1458	50	1
VFFS1-2300PM	30	2.0	8.0	1.8	108.0	32	1745	1454	50	1
VFFS1-4004PL	10	6.0	12.0	6.2	1.0	65	1680	1400	90	0
VFFS1-4007PL	10	6.0	12.0	5.8	1.7	60	1690	1408	80	0
VFFS1-4015PL	10	6.0	12.0	4.3	3.1	55	1690	1408	70	0
VFFS1-4022PL	10	5.0	12.0	4.1	4.5	52	1680	1400	70	0
VFFS1-4037PL	10	5.0	12.0	3.4	7.4	48	1690	1408	70	1
VFFS1-4055PL	10	4.0	12.0	2.6	10.5	46	1730	1441	70	1
VFFS1-4075PL	10	3.0	12.0	2.3	14.1	43	1730	1441	70	1
VFFS1-4110PL	10	2.0	12.0	2.2	20.3	41	1730	1441	60	1
VFFS1-4150PL	10	2.0	12.0	1.9	27.3	38	1730	1441	50	1
VFFS1-4185PL	30	2.0	8.0	1.9	34.0	36	1750	1458	50	1
VFFS1-4220PL	30	2.0	8.0	1.8	40.0	34	1750	1458	50	1
VFFS1-4300PL	30	2.0	8.0	1.8	54.0	32	1745	1454	50	1
VFFS1-4370PL	30	2.0	8.0	1.8	67.0	27	1750	1458	50	2
VFFS1-4450PL	30	2.0	8.0	1.7	80.0	26	1750	1458	50	2
VFFS1-4550PL	30	2.0	8.0	1.6	98.0	24	1755	1462	40	2
VFFS1-4750PL	30	2.0	8.0	1.5	129.0	28	1775	1479	40	2